

GBT BMC Firmware Upgrade User Guide
GIGABYTE Software

Document No.: GBT_BMC_FW_UP_GID_0007

Authors:

Sam Huang

Popcorn Li

Frank Cheng

Peter Lin

Duna Chung

Approved By:

Storm Chen

PROPRIETARY INFORMATION -- NOT FOR PUBLICATION

The information contained herein is the property of Gigabyte Technology Co., Ltd. and is supplied without liability for errors or omissions. No part may be reproduced or used except as authorized by contract or other written permission. The copyright and the foregoing restriction on reproduction and use extend to all media in which the information may be embodied.

Contents

0. General Information	3
0.1. Issue Control.....	3
0.2. Record of Changes.....	3
0.3. References.....	3
0.4. Acronyms.....	3
1. Files Hierarchy	4
2. Upgrade BMC Firmware in Linux.....	5
3. Upgrade BMC Firmware in Windows	6
4. Upgrade BMC Firmware in UEFI.....	7

Figures

Tables

0. General Information

0.1. Issue Control

This document was edited with **Microsoft Word, Version 2016**. The graphic drawings are originally sketched in **Microsoft PowerPoint Version 2016**.

0.2. Record of Changes

Table 0-1. Record of Changes

Issue	Date	Authors	Reason for Changes
1.01	2021/04/08	Popcorn Li	First release.
1.02	2021/09/30	Popcorn Li	Update Files Hierarchy and gigaflash version
1.03	2022/01/20	Frank Cheng	Disable V13 (2600) preserve conf function for now
1.04	2022/03/16	Frank.Cheng	Reenable V13 preserve conf function, Update some Files Hierarchy and gigaflash version
1.05	2022/06/28	Frank.Cheng	Add UEFI arm gigaflash tool, update uefi command for arm uefi.
1.06	2023/05/02	Peter Lin	Add “preserve” parameter to update BMC in preserve mode without ask preserve or not.
1.07	2024/06/18	Duna Chung	Support Insyde

0.3. References

NO	Document title

0.4. Acronyms

1. Files Hierarchy

Root Folder

```
|-- fw
  |-- 13xxxx.bin          ; AMI BMC firmware Binary, file name was BMC firmware version
  |-- image-bmc            ; Insyde BMC firmware Binary
|-- Tools
  |--x64                  ; Windows driver for windows x64
  |--x64_Win8              ; Windows driver for windows8 x64
  |--x86                  ; Windows driver for windows x32
  |-- gigaflash            ; GBT BMC flash tool for Linux
  |-- gigaflash.efi         ; GBT BMC flash tool for UEFI
  |-- gigaflash.exe         ; GBT BMC flash tool for Windows
  |-- gigaflash_arm         ; GBT BMC flash tool for ARM Linux
  |-- gigaflash_arm.efi     ; GBT BMC flash tool for ARM UEFI
  |-- gigaflash_x64         ; GBT BMC flash tool for Linux x64
  |-- gigaflash_x64.exe     ; GBT BMC flash tool for Windows x64
  |-- bmc_fw_upgrade_linux.sh ; Linux x86/ARM update BMC firmware script
  |-- bmc_fw_upgrade_uefi.nsh ; UEFI x86/ARM update BMC firmware script
  |-- bmc_fw_upgrade_win.bat ; Windows x86 update BMC firmware script
  |-- BMC_FW_Upgrade_User_Guide.pdf ; GBT BMC firmware upgrade user guide
  |-- BMC_Release_Note_12xxxx.doc ; GBT BMC firmware release note
```

2. Upgrade BMC Firmware in Linux

1. Get Linux **root permission**.
2. Change path to the root directory of Upgrade Package.
3. Run “`ami_bmc_fw_update_linux.sh`” for programing AMI FW.
Run “`insyde_bmc_fw_update_linux.sh`” for programing Insyde FW
4. For AMI FW, Enter "Y/y" to preserve configuration or Enter N/n to flash entire BMC.
Do you want to preserve configuration? (Y/n)
5. For Insyde FW, configuration preservation feature is not supported

User command:

NAME

`ami_bmc_fw_update_linux.sh` - Update script
`insyde_bmc_fw_update_linux.sh` - Update script

SYNOPSIS

`ami_bmc_fw_update_linux.sh` [OPTION]
`insyde_bmc_fw_update_linux.sh` [OPTION]

DESCRIPTION

Update BMC flash script. Below is option item:

CS

Select to update Active/Backup BMC firmware. (CS=1 only support on GBT Dual Platform).
0: Active
1: Backup
Default value is 0.

flashall

Flash entire BMC without warning message.
Default: Ask user preserve configuration or not

preserve

Flash BMC and preserve configuration without warning message.
Default: Ask user preserve configuration or not

x32

Set update tool to 32-bit mode
Default x86 64-bit mode

arm

Set update tool to arm mode (arm Linux only support 64-bit)
Default x86 64-bit mode

Example for flash entire BMC and select BMC address in address 0:

`ami_bmc_fw_update_linux.sh cs 0 flashall`
`insyde_bmc_fw_update_linux.sh cs 0 flashall`

3. Upgrade BMC Firmware in Windows

1. Open Command line with Windows [Administrator permission](#).
2. Change path to the root directory of Upgrade Package.
3. Run "ami_bmc_fw_update_win.bat" for programing AMI FW.
Run "insyde_bmc_fw_update_win.bat" for programing Insyde FW
4. Enter "Y/y" to preserve configuration or Enter N/n to flash entire BMC.
Do you want to preserve configuration? (Y/N)
5. For Insyde FW, configuration preservation feature is not supported

User command:

NAME

ami_bmc_fw_update_win.bat - Update script
insyde_fw_update_win.bat - Update script

SYNOPSIS

ami_bmc_fw_update_win.bat [OPTION]
insyde_fw_update_win.bat [OPTION]

DESCRIPTION

Update BMC flash script. Below is option item:

CS

Select to update Active/Backup BMC firmware. (CS=1 only support on GBT Dual Platform).
0: Active
1: Backup
Default value is 0.

flashall

Flash entire BMC without warning message.
Default: Ask user preserve configuration or not

preserve

Flash BMC and preserve configuration without warning message.
Default: Ask user preserve configuration or not

x32

Set update tool to 32-bit mode
Default x86 64-bit mode

Example for flash entire BMC and select BMC address in address 0:

[ami_bmc_fw_update_win.bat cs 0 flashall](#)
[insyde_bmc_fw_update_win.bat cs 0 flashall](#)

4. Upgrade BMC Firmware in UEFI

1. Change path to the root directory of Upgrade Package.
2. Run "ami_bmc_fw_update_uefi.nsh" for programing AMI FW.
Run "insyde_bmc_fw_update_uefi.nsh" for programing Insyde FW
3. Enter "Y/y" to preserve configuration or Enter N/n to flash entire BMC.
Do you want to preserve configuration? (Y/N)
4. For Insyde FW, configuration preservation feature is not supported

User command:

NAME

ami_bmc_fw_update_uefi.nsh - Update script
insyde_bmc_fw_update_uefi.nsh - Update script

SYNOPSIS

ami_bmc_fw_update_uefi.nsh [OPTION]
insyde_bmc_fw_update_uefi.nsh [OPTION]

DESCRIPTION

Update BMC flash script. Below is option item:

CS

Select to update Active/Backup BMC firmware. (CS=1 only support on GBT Dual Platform).

0: Active

1: Backup

Default value is 0.

flashall

Flash entire BMC without warning message.

Default: Ask user preserve configuration or not

preserve

Flash BMC and preserve configuration without warning message.

Default: Ask user preserve configuration or not

arm

Set update tool to arm mode

Default: x86 64 mode

Example for flash entire BMC and select BMC address in address 0 in x86:

ami_bmc_fw_update_uefi.nsh cs 0 flashall

insyde_bmc_fw_update_uefi.nsh cs 0 flashall

Example for flash entire BMC and select BMC address in address 0 in uefi-arm:

ami_bmc_fw_update_uefi.nsh cs 0 flashall arm

insyde_bmc_fw_update_uefi.nsh cs 0 flashall arm