


How to flash BIOS?

Kindly flash BIOS in DOS mode and do not use Windows flash utility.

1. Please first make sure the operating system is genuine version with latest Windows update (hot fix) and also update all drivers especially graphics driver.


2. Follow the instruction below to flash ME firmware in BIOS settings:

a) Please press [DEL] to enter BIOS and go to [Chipset] > [Intel ME FW Update]. Set as [Enabled], save and exit BIOS.



b.) Press [DEL] to enter BIOS again. Press the power button to force system turn off and wait at least 10 seconds

c.) Turn on system and enter BIOS [Main] to check [ME FW version].



d.) If [ME FW version] is 0.0.0.0, it means ME FW version can be updated, you can flash BIOS afterwards. If [ME FW version] is not 0.0.0.0, please return to the step 1 and re-do the steps again.

3. Flash BIOS in DOS mode. You may type "fptflash.bat" to flash BIOS.