

BIOS Update SOP


UEFI Shell

1. Download BIOS Package

2. Download BIOS update tool from AMI website.


URL: https://ami.com/en/?Aptio_V_AMI_Firmware_Update_Utility.zip

3. Copy “AfuEfix64.efi” into **SPI_UPD** folder.




4. Boot to UEFI Shell and into BIOS Package folder

5. Run “F.nsh” to start update BIOS.



6. Update BIOS successfully and reboot system.




Windows

1. Download BIOS Package
2. Download BIOS update tool from AMI website.

URL: https://ami.com/en/?Aptio_V_AMI_Firmware_Update_UTILITY.zip


3. Copy below file to BIOS Package

Folder	File
Tool\WIN\Win32	AFUWIN.EXE amifldr32.sys
Tool\WIN\Win64	AFUWINx64.EXE amifldr64.sys



4. Boot to Windows and into BIOS Package folder
5. Run "F.bat" to start update BIOS.

P.S. Your keyboard and mouse can't use when updating BIOS



6. Update BIOS successfully when windows is closed.