



Gigabyte_Server_BMC(AMI)_Web_update_BIOS_SOP_R02

Step-1 : Get BMC IP (method-1) (After system power on , can see BMC IP at left down side)



Gigabyte_Server_BMC(AMI)_Web_update_BIOS_SOP_R02


Step-1 : Get BMC IP (method-2) In BIOS setup page "Server Mgmt"




Gigabyte_Server_BMC(AMI)_Web_update_BIOS_SOP_R02

Step-2 : Open Web browser and key in BMC IP , in this case, BMC IP is 10.1.6.88

Then key-in **account** and **password** (**admin** / **password**)




Step-3 : Select and Click left side function icon “Maintain” (Chinese font : 維護)




Gigabyte_Server_BMC(AMI)_Web_update_BIOS_SOP_R02

Step-4 : Select and Click Firmware Update



Step-5 : Select and Click Firmware Type : BIOS



Gigabyte_Server_BMC(AMI)_Web_update_BIOS_SOP_R02

The screenshot shows the BMC web interface at 10.1.6.88. A confirmation dialog box is displayed in the center, asking for confirmation to start the firmware upgrade. The dialog text reads: "10.1.6.88 顯示 We will start the firmware upgrade now. Please reset system after BIOS update finish. Do you want to continue?". There are "確定" (Confirm) and "取消" (Cancel) buttons. The background interface shows the "韌體更新" (Firmware Update) page with instructions and a "開始韌體更新" (Start Firmware Update) button.

10.1.6.88 顯示

We will start the firmware upgrade now. Please reset system after BIOS update finish. Do you want to continue?

確定 取消

韌體更新

1. 此更新期間用於韌體映像傳輸的協議信息如下。要進行配置，請選擇韌體映像檔。

2. 韌體更新進行中，重刷頁面和關閉頁面將會中斷韌體更新的進行並且導致 BMC 無法正常進行韌體更新的運行，強烈建議不要再韌體更新時進行重刷頁面和關閉頁面。

Protocol Type: HTTP

更新類型: BIOS

選擇韌體映像檔

選擇檔案 image.RBU

開始韌體更新

The screenshot shows the BMC web interface during the firmware update process. The "Processing ..." status is displayed with a circular progress indicator. The progress bar at the bottom indicates "Flashing... (1% done)". The background interface shows the "韌體更新" (Firmware Update) page with instructions and a "Starting flash..." button.

10.1.6.88/#maintenance/firmware_update

韌體更新

1. 此更新期間用於韌體映像傳輸的協議信息如下。要進行配置，請選擇韌體映像檔。

2. 韌體更新進行中，重刷頁面和關閉頁面將會中斷韌體更新的進行並且導致 BMC 無法正常進行韌體更新的運行，強烈建議不要再韌體更新時進行重刷頁面和關閉頁面。

Protocol Type: HTTP

更新類型: BIOS

Processing ...

選擇韌體映像檔

選擇檔案 image.RBU

Starting flash...


Flashing... (1% done)

Gigabyte_Server_BMC(AMI)_Web_update_BIOS_SOP_R02


BIOS need match SCP version, so BIOS and SCP need two update steps

BIOS and SCP Both can use BMC Web update.

You can found SCP folder in package , as below case : BIOS F16w match SCP_1.06a



Then upload hpm file (as below case : MP32_AR0_scp_signed_1.06.20210615_SHA256.hpm)



Downloads > MP32-AR0_F16w3_web > SCP_1.06a

- HPM Firmware update supports the following components.
 - BOOT and APP
 - BIOS
 - ME
 - CPLD
- BIOS Firmware update

Select Firmware Image

選擇檔案 MP32_AR0_scp_signed_1.06.20210615_SHA256.hpm

Start firmware update

The dual image formation to be used for firmware update is displayed as follows.

Image to be Updated

Image

Preparing to flash...

Update All

List of Components

#	Component Name	Existing Version	Uploaded Version	Upgrade
1	BOOTFW	0.00.0	1.06.20210615	<input checked="" type="checkbox"/>

Proceed