


1. Open @Bios , and select flash.



2. Select your Bios , and open .



3. Flashing...



4. Reboot , and done .

