

VGA @BIOS


For GV-N980WF3-4GD

GV-N980WF3-4GD have two BIOS and it should change to different DVI output when BIOS flashing, please refer to more detail as below:

1. DP BIOS flashing (With DVI-I Port)



2. DD BIOS flashing (With DVI-D Port)



Step 1

Insert the DVI cable to DP Mode (DVI-I Port) and turn on the computer




Step 2

Run VGA @BIOS application



Step 3

Click "Flash" button then choose N980W34DP.FA1 BIOS




Step 4

When utility show "Flash BIOS success! Would you reboot the system"

Then Click "N" and shut down the computer

Step 5

Insert the DVI cable and change to DD (DVI-D Port) Mode. Then turn on the computer




Step 6

Run VGA @BIOS application



Step 7

Click “Flash” button then choose N980W34DD.FA1 BIOS



Step 8

When utility show “Flash BIOS success! Would you reboot the system”

Then Click “Y” to reboot the system and the BIOS flashing process is done.