

## GIGABYTE Fusion Firmware Update 3.0.8 Instructions

### GIGABYTE Fusion 韌體版本更新至 3.0.8 操作說明

#### 1. Execute Fusion\_v3.0.8


執行 Fusion\_v3.0.8



Fusion\_V3.0.8

#### 2. Please click on the “Connect” button shown on the installation window.


出現韌體安裝視窗，請先點選“Connect”。





3.Followed by clicking the “Program” button.

然後再點選 “Program” ，韌體將會開始安裝更新。



4.When the installation is complete, next to the “Result” will show as “Operation successful” . The Firmware is now successfully updated, please close the installation window.

安裝後，會在視窗下方出現” Operation successful” ，韌體更新完成，可關閉安裝視窗。

