




*If you open Aorus Engine , when flashing you need to close it .

1. Selec "Start"



2. Programming



3. Done, and replug keyboard

