




Update Thunderbolt FW SOP

Thunderbolt feature enable step:

1. Flash BIOS to latest Rev.
2. Reboot your BRIX.
3. Press “Del” or “Delete” key to enter into the BIOS setup screen.
4. Go to “Advanced \Intel Thunderbolt page” to “ENABLE” Thunderbolt FW update.



5. Press "F4" Key to Save change and exit and then boot into OS.




6. Boot to OS and then install Thunderbolt driver

7. Run TBT FW update tool : FwUpdateTool.exe





(Fw_Update_Tool_v2.0_20160401/ FwUpdateTool.exe)

8. Press Next to next Page





9. Click Browse icon and choose the Thunderbolt firmware path.
Firmware file name : “MKLP7BP_rev16.bin”






10. Press the icon “Next” to start flash Thunderbolt firmware.






11. Press "X" to exit flash tool



12. Please shutdown PC and Re-plug Power adapter.

13. Power on the system and into BIOS setup manual.

14. Go to Advanced page to “**DISABLE**” Thunderbolt FW update.



15. Press “F4” Key to save change and exit then boot into OS.