

# BIOS Release Notes

## TITLE

**SUBJECT:** MZ83-HD1 BIOS Release Notes version R07\_F18  
**System:** MZ83-HD1-000,G363-ZR0-AAX1-000,G363-ZR0-LAX1-000,  
G363-ZR0-AAX2-000,G363-ZR0-AAX4-000,G363-ZR0-LAX4-000

### About This Release

**Build Date:** 2025/04/02  
**BIOS Checksum:** 0x74F21A87 (32M)  
**Release Owner:** Candy.Wu

### BIOS Components/Contents

**Processor stepping(s) supported:** AMD Turin / Genoa Processors  
**System hardware configurations supported:** MZ83-HD1-000  
**PCB Version:** 1.x,3.x  
**Microcode updates versions:**

CPUID	Family	Microcode Update ID
Turin A0	Family 1Ah Model 00h-0Fh	0x0B00004D
Turin B0	Family 1Ah Model 00h-0Fh	0x0B001016
Turin C0	Family 1Ah Model 00h-0Fh	0x0B002032
Turin C1	Family 1Ah Model 00h-0Fh	0x0B00211E
Turin Dense A0	Family 1Ah Model 00h-0Fh	0x0B10000F
Turin Dense B0	Family 1Ah Model 00h-0Fh	0x0B101028

**IPMI support:**  
**AMI Kernel version:** 5.35\_0ACST\_PI1.0.0.3\_017  
**AGESA PI version:** TurinPI 1.0.0.3  
**OPROM version:**

OPROM	Version
AST2600	1.13.00

### Installation Notes

#### IMPORTANT NOTES:

1. Please extract the MZ83-HD1\_R07\_F18.zip to a bootable diskette that use FAT/FAT32 format

#### BIOS UPDATE INSTRUCTIONS FOR EFI Shell:

1. Insert USB flash drive to system for BIOS upgrade.

## BIOS Release Notes

2. Power on system and boot to Build-In Shell.
3. Enter your USB filesystem, like "fs0:" or "fsx:", "x" is your USB filesystem number
4. Flash script for bios update:
  - 4.1 For AMD EPYC 9004 series CPU, execute f\_GtoT.nsh
  - 4.2 For AMD EPYC 9005 series CPU, execute f.nsh
5. After bios flash finish, system must Power-Off to have the changes take effect.

### BIOS UPDATE INSTRUCTIONS FOR Windows:

1. Insert bios update USB flash drive.
2. Use Command Shell.
3. For AMD EPYC 9004 series CPU:
  - 3.1 Enter \Tool\WIN\afuwin32 and execute f\_GtoT.bat for Windows 32bit.
  - 3.2 Enter \Tool\WIN\afuwin64 and execute f\_GtoT.bat for Windows 64bit.
4. For AMD EPYC 9005 series CPU:
  - 4.1 Enter \Tool\WIN\afuwin32 and execute f.bat for Windows 32bit.
  - 4.2 Enter \Tool\WIN\afuwin64 and execute f.bat for Windows 64bit.
5. After bios flash finish, system must Power-Off to have the changes take effect.

### BIOS UPDATE FOR Easy BIOS Refresh:

1. The system supports remotely update BIOS if BMC existent.
2. Please download the Easy BIOS Refresh User Guide from Gigabyte website, target system support page.

### BIOS Version CHECK INSTRUCTIONS:

1. Power on system and press <DEL> during POST
2. The bios version shows on the first main page

## Known Issues/Workarounds

### Issues fixed in this version

R07

1. [Feature] Added system G363-ZR0-LAX4-000 support.

R06

- 1.[Fix] Fix PCIE compatibility when install GPU card.

R05

- 1.[Feature] Adjust the default maximum DDR speed.

R04

1. [Fix] SCE tool import/export issue.
2. [Fix] Fix Redfish sends data twice after the system has completed booting.
3. [Feature] Adjust the maximum speed limit during automatic memory training.

## BIOS Release Notes

4. [Feature] Add support for PCIe Re-Sizeable BAR functionality.

---

### R03

- 1.[Feature] Update AGESA 1.0.0.3.
- 2.[Feature] Support DDR speed up to 6400, but it requires manual adjustment in the BIOS settings.  
UMC Common Options => Enforce POR => Accept => Memory Target Speed set [DDR6400]
- 3.[Fix] Fix the issue where NVMe speed is reduced to Gen4 after a hot plug.
- 4.[Fix] Fix the issue where SEL reports incorrect DDR channel information when associated with CPU1.
- 5.[Fix] Fix the issue where the system ready to boot process gets stuck when the BMC is unresponsive.

---

### R02

- 1.[Feature] Update AGESA 1.0.0.2.
- 2.[Fix] Fix the network configuration switching issue in the BIOS Server Manager setup.
- 3.[Fix] Fix the issue where having too many installed devices causes the system to hang at the BIOS logo screen.
- 4.[Security] CVE-2024-0179, CVE-2024-21925, CVE-2024-21944, CVE-2020-10255.

---

### R01

1. First Release.
-