
BIOS update instructions

1. Click NP5XPNP08.exe
2. The system will automatically restart upon completion.



After the BIOS update process, the system will shut down automatically. This is normal. Please restart the system to complete the BIOS update.