BIOS Update Instructions

Before updating the BIOS, please note the following:

- Ensure that the AC adapter remains connected throughout the entire update process.

1. Run NH5xHH12.exe. When prompted, click "OK", and the system will restart to perform the first stage of the BIOS update.

2. After the system restarts, run NH5xHH12.exe once more. When prompted, click "OK", and the system will restart again to complete the full BIOS update process.

Note: The BIOS update process will be complete only after both update cycles have been successfully completed.