



BIOS update instructions

1. Click NP50RNx2-Y06.exe
2. Click OK then update BIOS. (Please do not remove the AC Power)



3. System will automatically restart after completion.



4. After the BIOS update process, system will shut down automatically. This is normal. Restart the system to complete the BIOS update.