BIOS update instructions

Before updating the BIOS, please note the following:

- Ensure that the AC adapter remains connected throughout the entire update process.
- ControlCenter must be installed on the system. If it is not installed, please visit the official product page, go to Support, and download and install ControlCenter from the Utility section.

Please follow the steps below to update the BIOS:

1. Run **WMeset.exe**. Click "Yes" when prompted, and the system will restart.

2. After the system restarts, run **FlashMEWinX64.bat** as an administrator. The system will restart again and perform the first stage of the update process.

3. After the system restarts again, run **FlashMEWinX64.bat** as an administrator once more. After the final restart, the BIOS update will be complete, and the system will be updated to the latest BIOS version.

