
BIOS update instructions

1. Click NP50RNx-Y12.exe
2. Click OK then update BIOS. (Please do not remove the AC Power)



3. The system will automatically restart upon completion.



After the BIOS update process, the system will shut down automatically. This is normal. Please restart the system to complete the BIOS update.