

# BIOS Release Notes

## TITLE

**SUBJECT:** 6LASH BIOS Release Notes version [R01](#)

### About This Release

**Build Date:** [2014/4/29](#)

**BIOS Checksum:** [0x4658A099](#) (4M), [0xAEEFDAE4](#) (8M)

**Release Owner:** gary.wu

### BIOS Components/Contents

**Processor stepping(s) supported:** supports Intel® Haswell and Haswell-Refresh processors

**System hardware configurations supported:** GA-6LASH-RH Rev: [0.1/0.2/1.0](#)

**Microcode updates versions:**

CPUID	Family	Microcode Update ID
<a href="#">306C1</a>	<a href="#">Haswell Processor A-0</a>	<a href="#">FFFF0013</a>
<a href="#">306C2</a>	<a href="#">Haswell Processor B-0</a>	<a href="#">FFFF0006</a>
<a href="#">306C3</a>	<a href="#">Haswell C-0</a>	<a href="#">00000017</a>

**IPMI support:**

**AMI Kernel version:** [Gbt\\_Kernel\\_E05\\_21](#)

**Intel CSI/MRC Package version:** [1.0.0.0](#)

**SPI Descriptor version:** [SPS\\_EN\\_03.00.05.128.0\\_PV-D\\_R\\_LPT](#)

**OPROM version :**

OPROM	Version
-------	---------

### Installation Notes

#### IMPORTANT NOTES:

1. Please extract the 6LASH\_[R01](#).zip to a bootable diskette that can boot to real DOS
2. Please don't load HIMEM.SYS or any other memory management SW in the diskette

#### BIOS UPDATE INSTRUCTIONS FOR DOS:

1. Insert USB flash drive to system for BIOS upgrade
2. Power on system and boot to USB flash
3. Execute FB.BAT for bios update
  - a. Execute "FB.BAT 3" only Flash BIOS Command line
  - b. Execute "FB.BAT 2" need move ME flash jump(AC off) to flash ME firmware
4. After bios flash finish, system will reboot automatically, please do not remove USB flash
5. System will restore DMI data after boot to DOS again, please wait the message below,  
["All BIOS flash steps are done! Please AC OFF and AC ON again. Thanks!"](#)
6. Done

## BIOS Release Notes

### BIOS UPDATE INSTRUCTIONS FOR Windows:

1. Insert bios update USB flash drive.
2. Use Command Shell
3. Execute \Tool\Win32\uf.cmd or \Tool\Win64\uf.cmd for bios update
4. After bios flash finish, Please reboot windows system

### BIOS UPDATE INSTRUCTIONS FOR LINUX:

1. Insert bios update USB flash drive.
2. Use Command Shell
3. Execute \Tool\LNx\afulnx32\uf.sh or \Tool\LNx\afulnx64\uf.sh for bios update
4. After bios flash finish, Please reboot windows system

### BIOS Version CHECK INSTRUCTIONS:

1. Power on system and press F2 during POST
2. The bios version shows on the first main page

## Known Issues/Workarounds

### Issues fixed in this version

R01

1. Update ME FW to SPS\_EN\_03.00.05.128.0\_PV-D\_R\_LPT.
2. Fine-tune USB30 mapping.

T02

1. Fixed the issue "RAID OpROM cannot be used".
2. Fine-tune the power consumption for memory.

F03

1. Fine-tune USB3.0 settings.

F02

1. Update verb table.
2. Correct the subsystem id for retek audio device.

F01

1. Add an item "Oboard Lan1 I/O ROM Option" in the setup menu to select "iSCSI" or "PXE" ROM.
2. Correct information of PCIE slots in SMBIOS.
3. Correct the setup item "Primary Display".

D04

1. [0015758], Fixed the issue "The user cannot press power button to trigger OS sleep or shutdown".
2. [0015757], Fixed the issue "PCI-E Option ROM function test fail , BIOS PCI-E Option ROM not match M/B print label".

## BIOS Release Notes

3. Correct SMBIOS information.
4. Update CPU microcode.
5. Fine-tune OpROM shadow behavior.
6. Enable CLTM function.

---

### D03

1. Fixed the issue "System hangs up on AC Loss for IPMI module when set nvram was fail".
2. Modify ITE8732 Pin 32 from PWM to GP31.
3. Fixed the issue "TPM warning message cannot be shown on the screen after PXE shadow".

---

### D02

1. Update setup menu module for E11b kernel code

---

### D01

1. Add CLTM support to RC.
  2. Change the behavior of sending command to BMC to log NMI event.
-