

# BIOS Release Notes

## TITLE

**SUBJECT:** MZ93-FS1 BIOS Release Notes version R03\_F19  
**System:** MZ93-FS1-000,R183-Z93-AAD1-000,R183-Z93-AAV1-000,  
R183-Z94-AAD1-000,R183-Z94-AAV1-000,R183-Z94-AAD2-000,  
R183-Z94-AAV2-000,R183-Z95-AAD1-000,R183-Z95-AAV1-000,  
R183-Z96-AAD1-000,R183-Z96-AAV1-000,R283-Z94-AAD1-000,  
R283-Z94-AAV1-000,R283-Z94-AAD2-000,R283-Z94-AAV2-000,  
R283-Z95-AAD1-000,R283-Z95-AAV1-000,R283-Z96-AAE1-000,  
R283-Z96-AAJ1-000,R283-Z96-AAE2-000,R283-Z96-AAJ2-000,  
R283-Z96-AAE3-000,R283-Z96-AAJ3-000,E283-Z91-AAD1-000,  
E283-Z91-AAV1-000,R183-Z93-LAJ1-000

## About This Release

**Build Date:** 2024/10/01  
**BIOS Checksum:** 0x740BB2EB (32M)  
**Release Owner:** Hex.Jan

## BIOS Components/Contents

**Processor stepping(s) supported:** AMD Turin / Genoa Processors  
**System hardware configurations supported:** MZ93-FS1-000  
**PCB Version:** 1.x,3.x  
**Microcode updates versions:**

CPUID	Family	Microcode Update ID
Turin A0	Family 1Ah Model 00h-0Fh	0x0B00004D
Turin B0	Family 1Ah Model 00h-0Fh	0x0B001016
Turin C0	Family 1Ah Model 00h-0Fh	0x0B00202B
Turin C1	Family 1Ah Model 00h-0Fh	0x0B002116
Turin Dense A0	Family 1Ah Model 00h-0Fh	0x0B10000F
Turin Dense B0	Family 1Ah Model 00h-0Fh	0x0B101021

**IPMI support:**  
**AMI Kernel version:** 5.35\_0ACST\_PI1.0.0.0\_014\_Patch3  
**AGESA PI version:** TurinPI 1.0.0.0  
**OPROM version:**

OPROM	Version
AST2600	1.13.01

# BIOS Release Notes

## Installation Notes

### IMPORTANT NOTES:

1. Please extract the MZ93-FS1\_R03\_F19.zip to a bootable diskette that use FAT/FAT32 format

### BIOS UPDATE INSTRUCTIONS FOR EFI Shell:

1. Insert USB flash drive to system for BIOS upgrade.
2. Power on system and boot to Build-In Shell.
3. Enter your USB filesystem, like "fs0:" or "fsx:", "x" is your USB filesystem number
4. Execute F.nsh for bios update
5. After bios flash finish, system must Power-Off to have the changes take effect.

### BIOS UPDATE INSTRUCTIONS FOR Windows:

1. Insert bios update USB flash drive.
2. Use Command Shell.
3. Enter \Tool\afuwin32 and execute f.bat for Windows 32bit.  
Or  
Enter \Tool\afuwin64 and execute f.bat for Windows 64bit.
4. After bios flash finish, system must Power-Off to have the changes take effect.

### BIOS UPDATE FOR Easy BIOS Refresh:

1. The system supports remotely update BIOS if BMC existent.
2. Please download the Easy BIOS Refresh User Guide from Gigabyte website, target system support page.

### BIOS Version CHECK INSTRUCTIONS:

1. Power on system and press <DEL> during POST
2. The bios version shows on the first main page

## Known Issues/Workarounds

1. Redfish is not ready.

## Issues fixed in this version