

BIOS Release Notes

TITLE

SUBJECT: MZ92-FS0 BIOS Release Notes version F01
System: R182-Z90-00,R182-Z91-00,R182-Z92-00,R282-Z90-00,R282-Z91-00,
R282-Z92-00,R282-Z93-00

About This Release

Build Date: 2020/04/15
BIOS Checksum: 0xDCFCDD3B (16M)
Release Owner: Ian.Liu

BIOS Components/Contents

Processor stepping(s) supported: AMD Naples Processors
System hardware configurations supported: MZ92-FS0,
Microcode updates versions:

| CPUID | Family | Microcode Update ID |
|--------|-------------------------|---------------------|
| Naples | Family 17h Model 00-0Fh | 08001230 |
| | | |

IPMI support:
AMI Kernel version: 5.013_NaplesCrb_0ACIJ022
AGESA PI version: NaplesPI 1.0.0.B
OPROM version :

| OPROM | Version |
|---------|---------|
| AST2500 | 1.09.0 |

Installation Notes

IMPORTANT NOTES:

1. Please extract the MZ92-FS0_F00a.zip to a bootable diskette that use FAT/FAT32 format

BIOS UPDATE INSTRUCTIONS FOR EFI Shell:

1. Insert USB flash drive to system for BIOS upgrade.
2. Power on system and boot to Build-In Shell.
3. Enter your USB filesystem, like "fs0:" or "fsx:", "x" is your USB filesystem number
4. Execute F.nsh for bios update
5. After bios flash finish, please reboot system

BIOS UPDATE INSTRUCTIONS FOR Windows:

1. Insert bios update USB flash drive.
2. Use Command Shell
3. Execute \Tool\WIN\Win32\f.bat or \Tool\Win64\f.bat for bios update

BIOS Release Notes

4. After bios flash finish, please reboot system

BIOS UPDATE INSTRUCTIONS FOR LINUX:

1. Insert bios update USB flash drive.
2. Use Command Shell
3. Execute \Tool\LNx\afulnx32\f.sh or \Tool\LNx\afulnx64\f.sh for bios update
4. After bios flash finish, please reboot system

BIOS Version CHECK INSTRUCTIONS:

1. Power on system and press during POST
2. The bios version shows on the first main page

Known Issues/Workarounds

Issues fixed in this version

F01

1. Fix R182-Z92 NVME slot HDD8 and HDD9 cannot detect NVME.

F00a

1. First Release.