

# BIOS Release Notes

## TITLE

**SUBJECT:** MZ33-DC0 BIOS Release Notes version F18  
**System:** MZ33-DC0-000,MZ33-DC1-000,R163-Z30-AAB1-000,  
R163-Z30-AAG1-000,R163-Z30-AAB2-000,R163-Z30-AAG2-000,  
R163-Z32-AAB1-000,R163-Z32-AAG1-000,R163-Z32-AAC1-000,  
R163-Z32-AAH1-000,R163-Z32-AAC2-000,R163-Z32-AAH2-000,  
E163-Z30-AAB1-000,E163-Z30-AAG1-000,R263-Z30-AAC1-000,  
R263-Z30-AAH1-000,R263-Z30-AAC2-000,R263-Z30-AAH2-000,  
R263-Z32-AAC1-000,R263-Z32-AAD1-000,R263-Z32-AAH1-000,  
R263-Z32-AAV1-000,E263-Z30-AAD1-000,E263-Z30-AAV1-000,  
R163-Z35-AAC1-000,R163-Z35-AAH1-000,R263-Z34-AAC1-000,  
R263-Z34-AAH1-000,R263-Z36-AAD1-000,R263-Z36-AAV1-000,  
R263-Z36-AAE1-000,R263-Z36-AAJ1-000,R263-Z37-AAC1-000,  
R263-Z37-AAH1-000,R263-Z30-AAC2-IF0-SW-001,  
R163-Z32-AAC1-IF0-SW-002,R163-Z34-AAC1-000,R163-Z34-AAH1-000,  
E163-Z34-AAC1-000,E163-Z34-AAH1-000,E263-Z34-AAE1-000,  
E263-Z34-AAJ1-000

## About This Release

**Build Date:** 2024/05/15  
**BIOS Checksum:** 0xBE64E400 (32M)  
**Release Owner:** Auto.Build(Ray.Xu)

## BIOS Components/Contents

**Processor stepping(s) supported:** AMD Genoa Processors  
**System hardware configurations supported:** MZ33-DC0-000, MZ33-DC1-000  
**PCB Version:** 1.x  
**Microcode updates versions:**

| CPUID      | Family                  | Microcode Update ID |
|------------|-------------------------|---------------------|
| Genoa B0   | Family 19h Model 10-1Fh | 0x0A101020          |
| Genoa B1   | Family 19h Model 10-1Fh | 0x0A101144          |
| Genoa B2   | Family 19h Model 10-1Fh | 0x0A101244          |
| Bergamo A0 | Family 19h Model 10-1Fh | 0x0AA00009          |
| Bergamo A1 | Family 19h Model 10-1Fh | 0x0AA00116          |
| Bergamo A2 | Family 19h Model 10-1Fh | 0x0AA00213          |

**IPMI support:**  
**AMI Kernel version:** 5.27\_GenoaCrb\_0ACQT024  
**AGESA PI version:** GenoaPI 1.0.0.B  
**OPROM version:**

## BIOS Release Notes

| OPROM   | Version |
|---------|---------|
| AST2600 | 1.12.00 |

### Installation Notes

#### IMPORTANT NOTES:

1. Please extract the MZ33-DC0\_F18.zip to a bootable diskette that use FAT/FAT32 format

#### BIOS UPDATE INSTRUCTIONS FOR EFI Shell:

1. Insert USB flash drive to system for BIOS upgrade.
2. Power on system and boot to Build-In Shell.
3. Enter your USB filesystem, like "fs0:" or "fsx:", "x" is your USB filesystem number
4. Execute F.nsh for bios update
5. After bios flash finish, system must Power-Off to have the changes take effect.

#### BIOS UPDATE INSTRUCTIONS FOR Windows:

1. Insert bios update USB flash drive.
2. Use Command Shell.
3. Enter \Tool\Win32 and execute f.bat for Windows 32bit.  
Or  
Enter \Tool\Win64 and execute f.bat for Windows 64bit.
4. After bios flash finish, system must Power-Off to have the changes take effect.

#### BIOS UPDATE FOR Easy BIOS Refresh:

1. The system supports remotely update BIOS if BMC existent.
2. Please download the Easy BIOS Refresh User Guide from Gigabyte website, target system support page.

#### BIOS Version CHECK INSTRUCTIONS:

1. Power on system and press <DEL> during POST
2. The bios version shows on the first main page

### Known Issues/Workarounds

### Issues fixed in this version