

# BIOS Release Notes

## TITLE

**SUBJECT:** MZA2-CE0 BIOS Release Notes version F00a

**System:** R162-ZA0-00, R262-ZA0-00

### About This Release

**Build Date:** 2020/08/07

**BIOS Checksum:** 0xDD33548A (16M)

**Release Owner:** Candy.Wu

### BIOS Components/Contents

**Processor stepping(s) supported:** AMD Naples Processors

**System hardware configurations supported:** MZA2-CE0,

**Microcode updates versions:**

CPUID	Family	Microcode Update ID
Naples	Family 17h Model 00-0Fh	08001230

**IPMI support:**

**AMI Kernel version:** 5.013\_NaplesCrb\_0ACIJ022

**AGESA PI version:** NaplesPI 1.0.0.B

**OPROM version :**

OPROM	Version
AST2500	1.09.0

### Installation Notes

#### BIOS UPDATE INSTRUCTIONS FOR EFI Shell:

1. Insert USB flash drive to system for BIOS upgrade.
2. Power on system and boot to Build-In Shell.
3. Enter your USB filesystem, like "fs0:" or "fsX:", "X" is your USB filesystem number
4. Execute F.nsh for bios update
5. After bios flash finish, please reboot system

#### BIOS UPDATE INSTRUCTIONS FOR Windows:

1. Insert bios update USB flash drive.
2. Use Command Shell
3. Execute \Tool\WIN\Win32\\*.bat or \Tool\Win64\\*.bat for bios update
4. After bios flash finish, please reboot system

#### BIOS UPDATE INSTRUCTIONS FOR LINUX:

## BIOS Release Notes

1. Insert bios update USB flash drive.
2. Use Command Shell
3. Execute \Tool\LNx\afulnx32\f.sh or \Tool\LNx\afulnx64\f.sh for bios update
4. After bios flash finish, please reboot system

### BIOS Version CHECK INSTRUCTIONS:

1. Power on system and press <DEL> during POST
2. The bios version shows on the first main page

## Known Issues/Workarounds

## Issues fixed in this version

F00

1. First Release.
  2. Based on MZ32-AR0 Naples BIOS F02.
-