

1. Right click on "ipfppm_sw.inf"
2. Click "Install"

