







AORUS ELITE 360 ICE / AORUS ELITE 360 Installation Guide


Package Contents / 包裝內容 / 包装内容 / パッケージ内容 / 패키지 내용물 / पैकेज की सामग्री / สิ่งของภายในกล่อง / Packungsinhalt / Contenido del paquete / Contenu de l'emballage / Содержимое упаковки / Paket içeriği / محتويات العبوة


a							
AORUS ELITE 360 ICE / AORUS ELITE 360							
b		c		d		e	
Thumbscrew Caps x 4	Daumenschraubenkappen x 4	Intel Studs x 4	Intel Stift x 4	AMD Studs x 4	AMD Stift x 4	Intel Backplate	Intel Rückplatte
螺帽 x 4	tapas de tornillos de mano x 4	Intel 螺柱 x 4	Estuche Intel x 4	AMD 螺柱 x 4	Estuche AMD x 4	Intel 後背板	Placa trasera de Intel
螺丝帽 x 4	bouchons de vis à main x 4	Intel 螺柱 x 4	Écrou Intel x 4	AMD 螺柱 x 4	Écrou AMD x 4	Intel 后背板	Plaque arrière Intel
サムスクリューキャップ x 4	крышки для винтов с ручкой x 4	Intel スタッド x 4	Intel лоток x 4	AMD スタッド x 4	AMD лоток x 4	Intel バックプレート	задняя панель Intel
손나사 캡 x 4	Başparmak Vida Kapakları x 4	Intel 스틱드 x 4	Intel Çivisi x 4	AMD 스틱드 x 4	AMD Çivisi x 4	Intel 백플레이트	Intel Arka Plaka
thumb screw caps x 4	أغطية مسامير بإبهام x 4	Intel स्टड x 4	دعامات Intel x 4	AMD स्टड x 4	AMD × 4 دعامات	Intel बैकप्लेट	لوحة خلفية إنتل
ฝาครอบน็อตแบบมือหมุน x 4		แกนยึด Intel x 4		แกนยึด AMD x 4		แผ่นรองด้านหลัง Intel	
f		g		h			
Radiator Screws x 12	Radiator-Schrauben x 12	Washers x 12	Unterlegscheiben x 12	Mounting Bracket	Montageschiene		
散热排螺丝 x 12	Tornillos para radiador x 12	垫圈 x 12	Arandelas x 12	安裝支架	Soport de montaje		
散热器螺丝 x 12	Vis pour radiateur x 12	垫圈 x 12	Rondelles x 12	安裝支架	Support de montage		
ラジエーターネジ x 12	винта для радиатора x 12	ワッシャー x 12	шайбы x 12	マウントブラケット	монтажная скоба		
라디에이터 나사 x 12	Radyatör Vidası x 12	와셔 x 12	Yıkayıcılar x 12	장착 브래킷	Montaj Braketi		
रेडिएटर स्क्रू x 12	مسامير رادياتور × 12	वॉशर x 12	× 12 غسالات	माउंटिंग ब्रेकेट	حامل تثبيت إنتل		
สกรูยึดหม้อน้ำ x 12		แหวนรอง x 12		ขายึด			


Intel LGA1851 / 1700 Socket


1851/1700: 78*78



h







Notice: Please remove the protective cover before installing

注意: 安裝前請先移除保護蓋

注意: 安裝前請移除保護蓋

注意: インストール前に保護カバーを取り外してください

주의: 설치 전에 보호 커버를 제거하십시오

सूचना: कृपया इंस्टॉल करने से पहले सुरक्षा कवर हटा दें

หมายเหตุ: กรุณาเอาฝาครอบป้องกันออกก่อนติดตั้ง

Hinweis: Bitte entfernen Sie die Schutzabdeckung vor der Installation

Nota: Por favor, retire la cubierta protectora antes de la instalación

Remarque: Veuillez retirer le couvercle de protection avant l'installation

Внимание: Пожалуйста, удалите защитную крышку перед установкой

Uyarı: Lütfen kurulumdan önce koruyucu kapağı çıkarın

قبل التثبيت غطاء الحماية ملاحظة: يرجى إزالة

The suggestion of the screw sequence

螺絲安裝順序建議

螺丝安裝順序建议

ネジの順番に関する推奨

나사 순서에 대한 권장 사항

स्क्रू लगाने के क्रम का सुझाव

ข้อแนะนำลำดับการขันสกรู

Vorschlag zur Schraubenabfolge

Sugerencia sobre la secuencia de tornillos

Suggestion pour la séquence des vis


Рекомендация по последовательности установки винтов

Vida sıralaması önerisi

اقتراح تسلسل المسامير


1 4


3 2



b

c

e



GIGABYTE™

AMD AM5 / AM4 Socket

AM5/AM4: 90°54

Notice: Please remove the protective cover before installing

注意：安裝前請先移除保護蓋

注意：安裝前請移除保護蓋

注意：インストール前に保護カバーを取り外してください

주의: 설치 전에 보호 커버를 제거하십시오

सूचना: कृपया इंस्टॉल करने से पहले सुरक्षा कवर हटा दें

หมายเหตุ: กรุณาเอาฝาครอบป้องกันออกก่อนติดตั้ง

Hinweis: Bitte entfernen Sie die Schutzabdeckung vor der Installation

Nota: Por favor, retire la cubierta protectora antes de la instalación

Remarque: Veuillez retirer le couvercle de protection avant l'installation

Внимание: Пожалуйста, удалите защитную крышку перед установкой

Uyarı: Lütfen kurulumdan önce koruyucu kapağı çıkarın

قبل التثبيت غطاء الحماية ملاحظة: يرجى إزالة

The suggestion of the screw sequence

螺絲安裝順序建議

螺丝安装顺序建议

ネジの順番に関する推奨

나사 순서에 대한 권장 사항

स्कू लगाने के क्रम का सुझाव

ข้อเสนอแนะลำดับการขันสกรู

Vorschlag zur Schraubenabfolge

Sugerencia sobre la secuencia de tornillos

Suggestion pour la séquence des vis

Рекомендация по последовательности установки винтов

Vida sıralaması önerisi

اقترح تسلسل المسامير

Installation / Cable Connection

Installation / 安裝 / 安装 / インストール / 설치 / स्थापना / การติดตั้ง / Installation / Instalación / Installation / Установка / Kurulum / التثبيت

Cable Connection / 連接線安裝 / 連接線安裝 / ケーブル接続 / 케이블 연결 / केबल कनेक्शन / การเชื่อมต่อสายเคเบิล / Kabelverbindung / Conexión de cables / Connexion de câbles / Подключение кабеля / Kablo Bağlantısı / الاتصال بالكابل

f

g

※ Set a fixed max speed of 3200 RPM for optimal cooling. The pump speed is controlled through voltage mode.

※ 建議設定固定的最大轉速為 3200 RPM，以保持最佳散熱效果。幫浦轉速透過電壓模式控制。

※ 建設設置固定最大轉速 3200 RPM，以保持最佳散熱性能。水泵轉速透過電壓模式控制。

※ 最適な冷却のために最大回転数を 3200 RPM に固定します。ポンプの速度は電圧モードで制御されます。

※ 최적의 냉각을 위해 최대 속도를 3200 RPM 으로 고정합니다. 펌프 속도는 전압 모드로 제어됩니다.

※ इष्टतम शीतलन के लिए अधिकतम गति 3200 RPM पर निर्धारित करें। पंप की गति वोल्टेज मोड द्वारा नियंत्रित होती है।

※ ตั้งค่าความเร็วสูงสุดคงที่ที่ 3200 RPM เพื่อประสิทธิภาพการระบายความร้อนที่ดีที่สุด โดยความเร็วของปั๊มจะถูกควบคุมผ่านโหมดแรงดันไฟฟ้า

※ Eine feste maximale Drehzahl von 3200 U/min für optimale Kühlung festlegen. Die Pumpengeschwindigkeit wird über den Spannungsmodus gesteuert.

※ Establezca una velocidad máxima fija de 3200 RPM para una refrigeración óptima. La velocidad de la bomba se controla mediante el modo de voltaje.

※ Réglez une vitesse maximale fixe de 3200 tr/min pour un refroidissement optimal. La vitesse de la pompe est contrôlée via le mode tension.

※ Установите фиксированную максимальную скорость 3200 об/мин для оптимального охлаждения. Скорость насоса регулируется в режиме напряжения.

※ Optimum soğutma için sabit maksimum hız 3200 RPM olarak ayarlanmalıdır. Pompa hızı voltaj modu ile kontrol edilir.

※ قم بتعيين سرعة قصوى ثابتة تبلغ 3200 دورة في الدقيقة لتحقيق التبريد الأمثل. يتم التحكم في سرعة المضخة من خلال وضع الجهد.

Contact Us

GIGA-BYTE TECHNOLOGY CO., LTD.

技嘉科技股份有限公司

Address: No.6, Baoqiang Rd., Xindian Dist., New Taipei City 231

地址：新北市231新店區寶強路6號

TEL: +886-2-8912-4000, FAX: +886-2-8912-4005

Tech. and Non-Tech. Support (Sales/Marketing) : <https://esupport.gigabyte.com>

WEB address (English): <https://www.gigabyte.com>

WEB address (Chinese): <https://www.gigabyte.com/tw>

Copyright

© 2026 GIGA-BYTE TECHNOLOGY CO., LTD. All rights reserved.

The trademarks mentioned in this manual are legally registered to their respective owners.

Disclaimer

Information in this manual is protected by copyright laws and is the property of GIGABYTE. Changes to the specifications and features in this manual may be made by GIGABYTE without prior notice.

No part of this manual may be reproduced, copied, translated, transmitted, or published in any form or by any means without GIGABYTE's prior written permission. For product-related information, check on our website at: <https://www.gigabyte.com>