

## Restore Your Operating System

Wiederherstellen Betriebssystem / Restaurer votre système d'exploitation / Restaurar el sistema operativo / Restaurar seu Sistema Operacional  
Ripristinare il sistema operativo / Восстановление Ваш операционной системы / Przywrócić systemu operacyjnego / Sizin İşletim Sistemi Geri Yükleme  
復原您的裝置 / 恢复您的设备 / あなたのGB-GZ1DTi7オペレーティングシステムを復元 / 귀하의 의 운영 체제를 복원

**There are two options for system recovery.**


- **Windows 10 Recovery Guide** : Press F9 while boot up the system and you are able to choose keep or remove your files and reinstall Windows without losing them.
- **GIGABYTE Smart Recovery** : A friendly instruction can be found while OS operating and able to restore to factory settings. All personal data will be removed.

**注意：兩種系統回復方式。**


- **Windows 10 Recovery Guide** : 開機時按F9啟動應用程式，這項功能可以讓使用者選擇保留或刪除個人文件後重新安裝Windows。
- **GIGABYTE Smart Recovery** : 預載在系統中，會在作業系統桌面提供使用者操作指示，可移除所有使用者文件與資料，回復到出廠預設值。

### 【GIGABYTE Smart Recovery】

**1** The recovery will be activated and you will see the option buttons on the window. Click on “Yes” to start it.  
點擊視窗上的“**Yes**”來啟動“GIGABYTE Smart Recovery”。



**2** After the system recovery is completed, you will see the option button on the window, please click on “Shutdown”.  
系統回復完成後，請點擊“**Shutdown**”關閉系統。




Note: A progress indicator bar will show on the window when the recovery process is running. Please make sure the AC-adaptor is plugged in and do not turn off the GB-GZ1DTi7.  
注意：在回復過程中，視窗會有進度指示顯示。請確保你的GB-GZ1DTi7插上電源，並且在回復過程中不要關閉電源。

### 【Windows 10 Recovery Guide】

- **Keep my files**  
Choose an account to continue. All apps will be removed, and settings will back to pure OS. All your personal files will be kept.  
選擇一個帳戶繼續。作業系統回復到初始環境，移除所有應用程式與設置，但保留個人文件與檔案。
- **Remove everything**  
All apps, settings and personal files will be removed.  
所有的應用程式，設置和個人文件將被刪除。
- **Just remove my files**  
Only personal data and files will be removed, but computer settings will be kept.  
保留設置檔，移除所有個人文件。
- **Fully clean the drive**  
The drive will be completely restored to factory default settings. It takes more time. Click on “Reset” to execute recovery functions.  
將硬碟回復到出廠設置，此一指令需要耗費較長的時間運作，請連續點擊“Reset”開始執行動作。

## 【Ambient LED APP】

Ambient LED APP allows you to enable or change the display mode for the Desktop PC System audio LEDs while in the Windows environment.  
Ambient LED APP提供您在作業系統中啟動或變更系統的LED顯示設定。



The screenshot shows the Ambient LED application window. It features a toggle switch for 'Ambient LED' which is currently turned on. Below the toggle, there are several mode selection options: Still Mode (Mode: 0), Pulse Mode, CPU Temperature Mode, Strobing Mode, Color Cycle Mode, Beat Mode, and Gaming Mode. A 'Color Choose' section is visible with a color selection bar. At the bottom, there is a 'Color Changing Time Interval' slider set to 1s, with other options at 3s, 5s, 7s, and 10s.

● Still Mode/恆亮模式/恒亮模式

● Pulse Mode/脈動模式/脉动模式

● CPU Temperature Mode/CPU溫度模式/CPU溫度模式

● Strobing Mode/閃爍模式/闪烁模式

● Color Cycle Mode/循環模式/循环模式

● Beat Mode/動感模式/动感模式

● Gaming Mode/遊戲模式/游戏模式

# GIGABYTE™



## GB-GZ1DTi7 Desktop PC Gaming GT Series

GB-GZ1DTi7 Desktop PC / PC ultra compact GB-GZ1DTi7 / PC Desktop GB-GZ1DTi7  
GB-GZ1DTi7 PC Desktop / PC Desktop GB-GZ1DTi7  
Ультеракомпактный ПК GB-GZ1DTi7: Комплект для самостоятельной сборки  
GB-GZ1DTi7桌上型電腦 / GB-GZ1DTi7台式计算机  
GB-GZ1DTi7 울트라·콘パクト PC키트 / GB-GZ1DTi7 울트라 컴팩트 PC 키트


### Quick Start Guide

Schnellstartanleitung / Guide de démarrage rapide / Guía de inicio rápido / Guia de Inicio Rápido  
Guida Rapida / Руководство по быстрой сборке / Skrócona instrukcja obsługi / Hızlı Başlangıç Kilavuzu  
快速入門使用者手冊 / 快速入门用户手册クイック・スタート・ガイド / 빠른 시작 설명서

## Getting Familiar with Your Unit


Lernen Sie ihr Geräts kennen / Découvrez votre unité / Conozca su dispositivo / Conhecendo a sua unidade  
Scopri la tua unità / Первое знакомство с устройством / Prezentacja zestawu / Cihazınızı daha iyi tanıyın  
認識您的裝置 (※系統操作溫度0°C-35°C) / 熟悉您的设备 / 自分のGB-GZ1DTi7について詳しくなろう / 장치 속지하기

### 【Front/前方面板】




- Power
- Headphone Microphone
- USB 3.0

### 【Side/側邊面板】



- DC-IN
- HDMI
- USB3.0
- USB3.1 Type A
- USB3.1 Type C

### 【Bottom/底部面板】



- AC-IN
- DVI-D
- DisplayPort
- HDMI
- Mic In/麥克風
- Line Out/音源輸出
- Line In/音源輸入
- RJ-45 LAN/網路插座 (10/100/1000Mbps)

\* Graphics card (Optional) outputs may vary by model.  
\* 顯示卡(選配)的輸出插座，因不同機型有所差異，請以實物為準。

