


GS-R114L Qualification Vender List - O.S. v1.0



O.S					
Manufacturer	Version	Service Pack	Normal SATA Supp	HostRAID Support	Remark
32-bit O.S.					
Windows	2000 Professional	SP4	V		
Windows	2000 Server	SP4	V		
Windows	2000 Advanced Server	SP4	V	V	
Windows	XP Professional	SP2	V	V	
Windows	Server 2003 Std.	SP1			
Windows	Server 2003 Ent.	SP1	V	V	
Linux	Red Hat AS 4.0				
Linux	Red Hat AS 4.0 Update1	Update1			
Linux	Red Hat AS 3.0 Update4	Update4			
Linux	Red Hat ES 4.0		V *1		*2
Linux	Red Hat ES 4.0 Update1	Update1	V *1		*3
Linux	Red Hat ES 3.0		V *1		
Linux	Red Hat ES 3.0 Update2	Update2			
Linux	Red Hat ES 3.0 Update3	Update3			
Linux	Red Hat ES 3.0 Update4	Update4			
Linux	Red Hat 9		V *1		*2
Linux	Red Hat ELAS 2.1				
Linux	Red Hat 8				
Linux	SuSE 8.2				
Linux	SuSE 9.0		X		*4
Linux	SuSE 9.0 SP2	SP2			
Linux	SuSE 9.2 Pro.		X		*4
Linux	SuSE 9.3 Pro.		V *1		*5
Linux	Fedora Core3				
Linux	Fedora Core4		V *1		
Linux	Free BSD 5.4		V *1		
Linux	Free BSD 4.9				
64-bit O.S.					
Windows	XP Professional 64bit Edition		V	V	
Windows	Server 2003 Std. 64bit Edition				
Windows	Server 2003 Ent. 64bit Edition		V	V	
Linux	Red Hat AS 4.0 (x64)				
Linux	Red Hat AS 4.0 Update1 (x64)	Update1			
Linux	Red Hat AS 3.0 Update4 (x64)	Update4			
Linux	Red Hat ES 4.0 (x64)		V *1		*2
Linux	Red Hat ES 4.0 Update1 (x64)	Update1	V *1		*3
Linux	Red Hat ES 3.0 Update4 (x64)	Update4			
Linux	SuSE 9.0 (x64)		X		*4
Linux	SuSE 9.0 SP2 (x64)	SP2			

*1 only install with SATA1&3

*2 can't insmod e1000.o with e1000-6.1.16, it's ok to use.

*3 make install incompletely with e1000-6.1.16, it's ok to use

*4 stop at preparing your hard disk formatting /dev/hda3as/... 100%

*5 after install completely, can't mount cdrom

