

FAQ

Category	Questions	Answers
Usage	Can it be a OS Drive ?	Yes, you have to disalbe CSM under BIOS due to it is NVMe interface
RAID Configuration	Can I configure RAID Array?	Yes, you can configure RAID 1 or RAID10. Default is RAID 0.
Setting	IIIO I nave to manually set un Biturteation/	No, You don't need to. The NVMe RAID controller is auto set as PCI e 3.0 x8 and devided into four PCIe 3.0 x 2
SSD Tool Box	Why it doesn't support SSDTool Box while others do ?	Since the RAID controller is not sending the information out.

