



UEFI SHELL FLASH HDMI FW SOP

1. Press F12 into BOOT MENU



2. Select UEFI: Built-in EFI Shell to EFI Shell



3. Check your USB device path.(ext. USB device is fs0: Removable HardDisk) and into USB device

```
EFI Shell version 2.31 [5.9]
Current running mode 1.1.2
Device mapping table
fs0      :Removable HardDisk - Alias hd6c0b blk0
          PciRoot(0x0)/Pci(0x14,0x0)/USB(0x2,0x0)/HD(1,MBR,0x0104CA07,0x3F,0
blk0     :Removable HardDisk - Alias hd6c0b fs0
          PciRoot(0x0)/Pci(0x14,0x0)/USB(0x2,0x0)/HD(1,MBR,0x0104CA07,0x3F,0
blk1     :Removable BlockDevice - Alias (null)
          PciRoot(0x0)/Pci(0x14,0x0)/USB(0x2,0x0)

Press ESC in 1 seconds to skip startup.nsh, any other key to continue.
Shell> fs0:

fs0:\> _
```

4. Run HDMI FW tool

```
fs0:\HDMI FW> AuxUpdate_0_4_fw0723.efi
AuxUpdate Version:0.4, firmware version 07_23
Bootloader:6.0.5
Current FirmwareVer:0x07_0x20
start to update downloading
Page:00
verifying
Download success,Please shutdown to reset the system!

fs0:\HDMI FW> AuxUpdate_0_4_fw0723.efi
AuxUpdate Version:0.4, firmware version 07_23
Bootloader:6.0.5
Current FirmwareVer:0x07_0x23
start to update downloading
Page:00
verifying
Download success,Please shutdown to reset the system!

fs0:\HDMI FW> _
```

- a. Update from current 0720 to new 0723
- b. Run tool again can check current already changed from 0720 to 0723