1. Select Connect



2. Select Program



3. Programing



4. Done



5. Re-plug the mouse