

# BIOS Release Notes

## TITLE

**SUBJECT:** MP72-HB0 BIOS Release Notes version [F21f](#)

**System:** [MP72-HB0-00](#)

### About This Release

**Build Date:** [2022/09/02](#)

**BIOS Checksum:** [0xC5F2334F](#) (32M)

**Release Owner:** Yuan.Chen

### BIOS Components/Contents

**Processor stepping(s) supported:** Ampere Altra MAX processors

**System hardware configurations supported:** MP72-HB0

**OPROM version :**

OPROM	Version
AST2600 VGA	

### Installation Notes

#### IMPORTANT NOTES:

- Please extract the zip file to a bootable diskette that use FAT/FAT32 format

#### BIOS UPDATE FOR Easy BIOS Refresh:

1. The system supports remotely update BIOS if BMC existent.
2. Please download the Easy BIOS Refresh User Guide from Gigabyte website, target system support page.

#### BIOS Version CHECK INSTRUCTIONS:

1. Power on system and press <DEL> during POST
2. The bios version shows on the first main page

#### BIOS UPDATE INSTRUCTIONS FOR Web UI:

1. Connect BMC\_IP by Internet browser.
2. Click Web-UI sub-page button "Update".
3. Select Firmware Type to ROM.
4. Use Command Shell.
5. cd to /RBU.
6. Select File Path to image.RBU.
7. Click Upload.

#### BIOS UPDATE INSTRUCTIONS FOR GbtUtility:

1. Please copy the BIOS\_ZIP file to GbtUtility folder.
2. Use Command Shell.
3. cd to GbtUtility folder.
4. Execute "java -jar GbtUtility.jar -H [BMC\\_IP](#) update bios [BIOS\\_ZIP](#) 1".

## BIOS Release Notes

### Known Issues/Workarounds

### Issues fixed in this version

F21f (2022/09/02)

1. Support BIOS master and backup hpm image.
-